

EnviroSeal® OCX Platinum is a two-component, open-cell spray polyurethane foam (ocSPF) insulation system with a light-density formulation designed to meet AC-377 Appendix X requirements. EnviroSeal OCX Platinum requires mixing prior to use. For more information refer to the Application Section of this guide.

HANDLING AND STORAGE

Exercise caution when removing bungs from containers, as the contents may be under pressure. Always loosen the small bung first to allow any built-up gas to escape before fully removing. Minimize exposure to vapors and avoid prolonged inhalation. Additional information is available in the AX-119 publication by the Polyurethanes Industry.

Storage

Unopened resin (B-side) has a shelf life of six (6) months from the date of manufacture when stored in original containers at temperatures between 50°F and 80°F in a dry, well-ventilated area.

To preserve product quality;

- Do not expose to direct sunlight
- Avoid placing drums directly on cold concrete floors

Product Change-Over

Mixing incompatible resin types can cause cross-contamination. It is the applicator's responsibility to follow proper procedures to prevent resin contamination. When switching the "B" side (resin), especially closed cell to open cell, it is crucial to fully drain the supply hoses, recirculation lines, and drum pumps.

APPLICATION

Equipment

It is the applicator's responsibility to have a complete understanding of all equipment specifications, technical requirements, and safe operating procedures related to spray polyurethane foam application.

EnviroSeal OCX Platinum requires mixing for a minimum of 30-minutes before the application. Mixing speed may be reduced after the initial 30-minute mix period but the material should continue to be mixed throughout the application. EnviroSeal polyurethane foam should be applied using commercial-grade spray equipment specifically designed for this purpose by a qualified professional applicator. For optimal performance, 2:1 transfer pumps are recommended used with an internal mix type spray foam gun.

Equipment Settings

Pre-Heaters: (A) Component - ISO	120°F – 140°F
Pre-Heaters: (B) Component - Resin	120°F – 140°F
Hose Heat	120°F – 140°F
Fluid Pressure	1,000 – 1,500 psi - Dynamic
Mixing Ratio	1:1 By Volume
Recommended Mix Chamber/	10 – 15 Lbs./Minute (i.e.
Module Size:	01-GRACO AR4242)

Mixing Requirements

Resin (B side)	Mixing Required for a minimum of 30-minutes before the application.
	Continue to mix material throughout the application.

These are the recommended settings. Actual settings may vary throughout application based on equipment, substrate, and ambient temperatures. Equipment must be able to maintain all ratios and settings.

Project Conditions

It is the applicator's responsibility to ensure that the spray polyurethane foam system is applied within its recommended parameters. For optimal performance, the recommended substrate temperature during application is between 40°F and 120°F.

Application Parameters

Storage Temperature	50°F – 80°F
In Use Temperature	80°F – 90°F
Ambient Air Temperature	40°F – 120°F*
Substrate Temperature	40°F – 120°F*
Moisture Content of Substrate	Less Than 19%

* For temperatures below 40°F refer to the Cold Weather section on page 2

Processing Requirements

All material must be a minimum of 80°F before dispensing.

EnviroSeal OCX Platinum adheres to a variety of construction materials, including but not limited to wood, masonry, concrete, and metal. All surfaces must be clean, dry, and free of dew or frost before spraying. Metallic surfaces must be free of oil, grease, mill scale, rust, or other contaminants to ensure proper adhesion.

Avoid spraying into or under rising foam, as this can lead to elongated cell structures, which may cause dimensional stability issues, shrinkage, or cracking. As with all spray polyurethane foam (SPF) systems, improper application techniques should be avoided.

Any foam that is improperly applied or off-ratio must be completely removed and replaced with properly installed spray polyurethane foam.

Moisture

Polyurethane foam should not be applied on surfaces which are wet or have been affected by rain, condensation, dew, or frost. The substrate moisture content should not exceed 19%. Any foam applied to substrates with moisture content exceeding 19% must be completely removed. The substrate must be allowed to dry before reapplication.

Cold Weather

In cold weather conditions (below 40°F), applications require adjustments to material temperatures and application techniques. Use of additional barrel warming or other methods of keeping the drums warm is vital. Additionally, warming the substrate using thinner lifts and/or picture framing stud cavities can improve adhesion.

Ventilation

It is the contractor's responsibility to ensure that mechanical ventilation is provided during and after the application of spray foam. Minimum ventilation during application is 0.3ACH. For 1-hour worker re-entry or 2-hour re-occupancy 10ACH is required. For more detailed guidance, refer to the "Guidance on Ventilation During Installation of Interior Applications of High-Pressure Spray Polyurethane Foam" published by the American Chemistry Council, Spray Foam Coalition.

Exposure to Heat

It is the contractor's responsibility to ensure that the foam maintains separation from heat emitting surfaces. The maximum in-service temperature is 180°F and the material should be kept a minimum of 3" from these surfaces. Any cutting, brazing, or other work with an open flame or sparks should be kept clear of the foam.

Exposed Foam

Sprayed polyurethane foam surfaces must be protected from direct UV exposure. Prolonged exposure to sunlight will cause dusting and discoloration of the foam. Open cell foam should not be left in direct sunlight or be subjected to UV exposure. For further application information, consult a Quadrant Performance Materials Technical Representative.

SAFETY

Personal Protective Equipment (PPE)

The process of spraying polyurethane foam creates atomized material. Inhalation and direct exposure to these fine droplets must be avoided.

Applicators should wear appropriate Personal Protective Equipment (PPE) as recommended by the Center for the Polyurethanes Industry (CPI) for high-pressure spray foam applications. Required precautions include but are not limited to the use of a full-face mask or hood with a fresh air supply; coveralls/suits to protect skin and clothing; and appropriate gloves for handling wet and dry materials as well as cleaning products.

For additional information on PPE visit www.spraypolyurethane.org.

In the event of a spill or material splashing on a worker keep all PPE in place while removing any garments/outerwear which has been compromised. Only after the compromised items have been moved aside, remove the PPE from the worker, move to fresh air, and assess. If breathing becomes irregular immediately call 9-1-1 and administer First Aid. If the eyes are affected, thoroughly flush the affected eye(s) with clean water and assess. If the material is ingested, do NOT induce vomiting and seek medical help immediately.

Environmental Precautions

If the product causes environmental contamination, notify the appropriate authorities. Prevent material from entering sewers, surface water, or groundwater systems.

Spills

In the event of a spill, it is the contractor's responsibility to act quickly to minimize the spill and contain the material. Activities include restricting access to the area allowing only authorized personnel in proper PPE; contain the spill using absorbent materials (kitty litter or similar); properly clean-up the spill and place the waste in a suitable container for proper disposal; label the waste materials accordingly following all local, state, and federal guidelines.

TECHNICAL ASSISTANCE

For additional support, contact Quadrant Performance Materials Technical Services or Product Engineering Departments at 972-542-0072.

DISCLAIMER

The technical and processing information in this document serves as a general guideline. Always refer to the Safety Data Sheet (SDS) and product label before use.



📍 200 Industrial Blvd.
McKinney, Texas 75069

☎ 972-542-0072

🌐 www.QuadrantPM.com